

## 9cc Evo Tonearms - Anti Skate Weight



Fitting the stub.

The Anti Skate Weight support stub is not pre-fitted. This should be fitted when the TT is setup in its final position.

The thread should be looped over the front of the stub (the threaded end) and then the stub should be gently screwed into the rear of the tonearm support (noting that the threaded hole is cut at an angle).

