

# WiiM Mini

WiiM Home app



**Turn any audio gear smart**

## 1 Connect WiiM Mini to your stereo system

Connect WiiM Mini to your stereo system through **AUX OUT** (not AUX IN) or **SPDIF**. Plug in USB cable to Type-C power port.



**Setup** – Press/hold play button on the WiiM Mini for 3 seconds or longer.

**Restore to factory setting** – Press/hold play button on the WiiM Mini for 10 seconds or longer.

**Bluetooth pairing** – Press/hold volume +&- for 2 seconds or longer.

## 2 Download the WiiM Home app

Open the WiiM Home app when you're ready to get started. You'll use it to set up and control your WiiM Mini.




### Connect to WiiM Home app

1. Turn on Bluetooth in your device's settings.
2. Back to the WiiM Home app, choose the device you found and tap "**Set up**".
3. Allow the location permission to discover the nearby network to set up the Wi-Fi network for WiiM Mini.

### 3 Fill your home with music

Stream your favorite music, radio stations through Wi-Fi or Bluetooth. Having multiple WiiM Mini devices, play streaming music the whole house. Or plug in a stereo component—like an amplified turntable, CD player, or MP3 player—and cast music to multiple WiiM Mini connected speakers at once.



### Need help?

WiiM Home app: Settings/Support

Website: [wiimhome.com/support](http://wiimhome.com/support)

Email: [support@wiimhome.com](mailto:support@wiimhome.com)

Product user guides: [wiimhome.com/guides](http://wiimhome.com/guides)

 @wiimhome

 @wiimhome

 @wiimhome

 @wiimhome

**Use Restriction:** The device for operation in the band 5150–5350 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.