WiiM Quick Start Guide

WiiM Voice Remote works with WiiM Mini, WiiM Pro and WiiM Pro+. Use WiiM Voice Remote to control your favorite WiiM device without your phone.



Voice button – Push to talk to use Alexa. When speak, press and hold this button. Release when finish.

Preset shortcuts - Customize these presets within the WiiM Home App.

How to pair with WiiM device

Press and hold the "Source" and "Mute" buttons at the same time for 2 seconds, then go to the WiiM Home App and select the **Device** tab > Tap **the device setting gear icon** > **Add or Delete a WiiM Remote**.

For help, visit https://www.wiimhome.com/support